



CORPORATE HEADQUARTERS

14651 North Dallas Parkway
Suite 500
Dallas, TX 75254

Telephone 214-357-6181
FAX 214-351-0194
www.peerlessmfg.com

May 12, 2010

Jon Sacks
Director, Development and Transactions
Mirant Corporation
1155 Perimeter Center West
Atlanta, GA 30338-5416

Dear Jon,

Per our discussions with Kiewit on start-up emissions – I offer the following:

The start-up sequence for the CO/SCR systems involves several steps:

- 1) CT start-up
- 2) CT purge and Peerless duct purge per NFPA
- 3) Catalyst ramp heat-up
- 4) Catalyst reagent vaporization
- 5) Reagent injection
- 6) Catalyst adsorption
- 7) CEMs calibration loops
- 8) SCR feed-back trim control loop.

These overlapping steps will result in an estimated 30 minute start-up in order to reach steady-state.

Best Regards,

Tim Shippy
Environmental Systems